



### **Water Supply Converter Operating Instructions**

- 1.** Connect to competitor's water supply at the Gardena female quick coupler.
- 2.** Turn water supply on and then activate the squeeze handle.
- 3.** Verify a minimum flow of 2 gallons per minute is achieved through the purger.



### **Water Supply Converter Operating Instructions**

- 1.** Connect to competitor's water supply at the Gardena female quick coupler.
- 2.** Turn water supply on and then activate the squeeze handle.
- 3.** Verify a minimum flow of 2 gallons per minute is achieved through the purger.