



In-Valve Battery Sensor Bracket Installation Instructions




1. Clean the surface of the bracket with an alcohol wipe.
2. Feed the LED through the bracket as shown.
3. Slide the plate over the cable through the slot.




4. Remove the adhesive backing and secure the parts together as shown.
5. Slide bracket between the case and a cell in a safe and visible location.

Note: Do not place bracket on hose, tubing or side handles.

In-Valve Battery Sensor Bracket Installation Instructions



1. Clean the surface of the bracket with an alcohol wipe.
2. Feed the LED through the bracket as shown.
3. Slide the plate over the cable through the slot.



4. Remove the adhesive backing and secure the parts together as shown.
5. Slide bracket between the case and a cell in a safe and visible location.

Note: Do not place bracket on hose, tubing or side handles.