

User Friendly App and Web Portal

 **Advanced**
BatterySteward®
with tracking intel



Easy to Install - Simple to Use

tracking intel



Install **Tracker**
on your batteries.



Download the IOS or
Android application.



Monitor, track, and
control your battery.



www.flow-rite.com/battery-steward

For technical support, call
616-583-1700 or email
info@flow-rite.com



flowrite
960 74th Street SW
Byron Center, MI 49315
   
MM-002-0722



NOW AVAILABLE FOR

Sealed Batteries

Monitor. Track. Control.



Manage the care for
lead-acid batteries by
tracking information
wirelessly. Make informed
predictions and decisions
for maintaining the health
of your investment.




Advanced
BatterySteward®
with tracking intel

www.flow-rite.com/battery-steward

Take Control of Battery Management

SENSORS WIRELESSLY COMMUNICATE USEFUL DATA:



Knowing the condition of your forklift batteries will help you get the most out of your investment. Take the guesswork out of maintaining this essential asset.

Gateway Connection and Range



What About the Data?



Know when your battery is being watered. **Advanced Battery Steward** pressure sensor is the only sensor that records the exact time and date a watering event occurs.



Measurement of impact could indicate that a battery was mishandled. This sensor tracks potential misuse or improper handling of equipment.



A full time temperature monitor to know current and historical temperatures.



Voltage measurement indicates when a battery is fully charged or not. Half voltage measurement helps you discover a failing cell within a battery.



A remote light shows **red** if a battery needs to be watered or **green** when fluids are at proper levels. The **Tracker** also stores electrolyte level history showing usage and data to help predict the life of the battery.



Current readings will help with fleet utilization. Track amp hours and battery usage time to help predict the longevity of your equipment.