


1-1/8" BILGE BUNDLE WITH PUMP

1-1/8" Qwik-Lok™, MB-005

Quickly install this Bilge bundle which comes with a handy 1000 GPH pump. It includes everything you need to remove water from your bilge area.



INSTALLATION TIPS:

- Locate bilge pump in the lowest possible location of the bilge area.
- Install thru-hull fitting above water line.
- Secure all fittings. Marine sealant may be used with thruhull fitting.
- Once assembled, slide Qwik-Lok locking ring forward, into the locked position.
- Cut hose to desired length.

| ITEM | DESCRIPTION | QTY |
|------|-----------------------------------|-----|
| Α | Bilge pump, Rule, 1000 GPH | 1 |
| В | Thru-hull, straight, 1-1/8" | 1 |
| С | Qwik-Lok socket, straight, 1-1/8" | 2 |
| D | Hose Clamp | 2 |
| Е | 6' of Hose, 1-1/8" | 1 |



