
# **User Friendly App and Web Portal**









www.flow-rite.com/battery-steward

For technical support, call 616-583-1700 or email info@flow-rite.com









### **Take Control of Battery Management**

#### SENSORS WIRELESSLY COMMUNICATE USEFUL DATA:





Knowing the condition of your lead-acid batteries will give you maintenance freedom while protecting your investment.

### What About the Data?



Know when your battery is being watered. **Advanced Battery Steward** pressure sensor is the only sensor that records the exact time and date a watering event occurs.



A full time temperature monitor provides data to predict battery trouble.



Measurement of impact could indicate that a battery was mishandled. With this information you may decide to adjust the way a battery is loaded/unloaded from a forklift.





Voltage measurement indicates when a battery is fully charged or not. Half voltage meaurement helps you discover a failing cell within a battery.



A remote light shows **red** if a battery needs to be watered or **green** when fluids are at proper levels. The **Tracker** also stores electrolyte level history showing usage and data to help predict the life of the battery.



Current readings will help with fleet utilization.
Determine a rotation schedule based on current in/out measurements to equally use deep cycle batteries.

## Easy to Install - Simple to Use



Install *Tracker* on your batteries.



Download the IOS or Android application.



Monitor, track, and control your battery.